

Wintex wiring and installation info:

Wintex 1000S / 2000 / 3000

Wrench for probe 20 mm, 30 mm, special

-Thick black and the thick red wire must be connected to the battery red to+, black to -.

-Cable 1 and 2 starter switch (Box I2 & + 12v)

-Cable 3 foot pedal (left and bottom right connector) and then to brake light. (Box I1)

-Cable 4 frame (ground) (box -)

-Check hydraulic oil and engine oil before you start the motor. The oil had to be drained for transport. (Pump presser up-80 psi down-50 psi don't adjust pressure manually it is preset and tested but use the correct solenoid and hose to connect).
Use only Hydraulic oil - DIN HLP22

2-way switch for turns on W2000 older Logo(one small logo with out program screen on large logo:

There is two wires the red one must go to + and the second one to I12. We hope that it is the right program you have in the LOGO, if not you must change the LOGO too

Hose guide adjustment:



Hydraulic connectors to block:

B1	foot down	bottom on cylinder
A1	foot up	top on cylinder
A2	probe up	bottom on cylinder
B2	probe down	top on cylinder
H	hammer H	
A3	rotation B	
B3	rotation A	(rotation – clock turn)