

Mounting the Wintex MCL3T on the tractor

Does only concern the Wintex MCL3T for soil samples in 2 m depth.



The Wintex MCL3T must be mounted on the tractor by means of a hydraulic cylinder with top link. The hydraulic hoses must be mounted on the top link.

Wintex MCL3T during transportation



It is necessary to make a frame or another assembly so that the mast can rest against the driver's cab during transportation.

When driving the tractor, and the soil sampler is not in use, the mast must always rest again. This does also concern driving from one spot to another for taking samples.

Dismounting the Wintex MCL3T



Before dismounting the Wintex MCL3T the probe must be dismounted. To avoid tipping over make sure that the drilling head is down.



